
Operating procedures

Placing in service

Follow these steps to place the BIPC in service:

- 1 Verify that the BIPC is installed correctly, that Meridian 1 data fill is completed, and that all data and power cables are connected securely.
- 2 Plug in the power supply. (The red power indicator lights.)
- 3 Press the BIPC RESET button. This sends a <CR> to the Meridian 1.

The BIPC is now ready. No further adjustment is required for normal operation.

Restoring service

If, for any reason, service through the BIPC is interrupted, restart the BIPC by pressing the RESET switch. However, if the BIPC itself is faulty, it may be necessary to replace the unit. Additionally, check the SDI port to be sure that it is set and operating properly.

Repair procedure

The BIPC has no field replaceable parts other than the power supply. Replace a faulty BIPC with a working unit to ensure continued operation. To do so, follow the replacement procedures for defective Meridian 1 units.